



Brawlerfab.com

[sales@brawlerfab.com](mailto:sales@brawlerfab.com)

## LP6 Behind the Grille Addendum

### **Panel behind the grille – REQUIRED FOR ALL LP6 LIGHTS BEHIND THE GRILLE**

1. Using the picture below, mark the location for the pilot hole to be drilled for a 7” hole saw.
2. Repeat on opposite side of the grille using the corresponding location.
3. Drill your pilot hole from the front of the grille using the same size drill bit that is on your hole saw. (This is to be done only after the grille has been removed from the truck)
4. Flip your grille over and using the pilot holes drilled in the previous step, cut the 7” hole with the 7” hole saw. (before you pull the trigger, ensure the entire hole will remain on the panel and not go over any edge) \*\*\*Be careful not to go too far and cut into the honeycomb grille\*\*\*



You can now follow the rest of the installation guide to complete your installation.

**Thank you,**

**BrawlerFab**